

## **SDI Booster Pump** Kit Instructions

Industry Leader in RO Expertise and Membrane Applications since 1983™

- 1. Open kit and check that all items are present:
  - Pump
  - Pressure Gauge
  - Pressure Regulator
  - Power supply (appropriate for the voltage that was ordered)
  - 3/8" Tubing (approx. 3 feet)

Ensure that the power supply is connected to the pump.

2. Use the 3/8" tube to connect the feed water supply to the "IN" port of the pump kit.





3. Connect the tubing that comes with the SDI-2000 unit from the pump "OUT" Port to the "IN" port on the SDI-2000 unit. Connect the filter holder (without a filter) to the "OUT" port on the SDI test kit, and position the filter holder over a drain.



- 4. To start the pump, plug the pump power supply into a power source.
- 5. Turn the pump regulator to adjust the pressure to 40-60 psi.
- Unplug the pump, and follow the instructions to set up the SDI-2000.
- Plug the pump power supply in to begin the test. Follow the instructions with the test kit to complete the test.
- 8. When finished, unplug the pump and drain the unit.

